



USER GUIDELINES




INSTALLATION GUIDELINES USING GROUND SPIKE*




*Ground spike not included

INSTALLATION GUIDELINES USING GROUND SOCKET



STORAGE AND CARE



FOLD AND REMOVE AFTER USE

STORE SAFELY OUT OF REACH OF CHILDREN
CHILDREN SHOULD NOT PLAY WITH THIS PRODUCT

Check clothes dryer for damages before each use

Do not use a damaged dryer

Do not use the dryer for any purpose other than to hang and dry washing